


Front



Back

Bag Size: 35cm(W) x 40cm(H) x 10cm(B)

Style: SBB (Bottom Opening Bag)

----- Printing Area : 25cm(W) x 25cm(H)

(Do not print beyond this area)