


Front



Back

Bag Size: 38cm(W) x 42cm(H) x 12cm(B)

Style: SBB (Bottom Opening Bag)

----- Printing Area : 28cm(W) x 26cm(H)

(Do not print beyond this area)