


Front



Back

Bag Size: 48cm(W) x 35cm(H) x 15cm(B)

Style: SBB (Bottom Opening Bag)

Printing Area : 38cm(W) x 25cm(H)

(Do not print beyond this area)

